

2005 HONDA ODYSSEY

MAKE CONNECTIONS AT WIPER MOTOR IN ENGINE COMPARTMENT.
 NOTE THAT MANUAL FAST IS DISENGAGED WHEN RAIN TRACKER MODE IS SELECTED
 REQUIRES EXTERNAL RELAY (NOT SUPPLIED)
 BREAK INTO BOTH FAST AND SLOW WIRES AS SLOW

RELAY CONTROL MODULE

