



Make connections at the wiper motor in the engine compartment.
 Note that manual fast is disengaged when Rain Tracker mode is selected.
 Requires external relay (Not supplied)
 The numbers on the relay are for a commonly available automotive relay.
 Break into both the fast and slow wires

RAIN TRACKER INTERFACE WIRING DIAGRAM
 WIPER SYSTEM CLASS:
2011 Honda Odyssey