



To install a Rain Tracker, you must access the wires going to the wiper motor winding terminals. locate the Rain Tracker control module under the dashboard, and run wire to the wiper motor windings-- you will need to extend the wires from the RainTracker, and go through the firewall.

HOT SIDE SWITCHING
WIPERS RUN WHEN 12V APPLIED TO WIPER MOTOR SLOW OR FAST TERMINALS. MOTOR COMMON AT GROUND.

RainTracker™
VEHICLE INTERFACE
WIRING DIAGRAM

© 2004 OPTO-ELECTRONIC DESIGN, INC